


# SCHEMATIC DIAGRAM



- SELECTOR S<sub>1</sub> (a-j)
1. PHONO
  2. FM AUTO
  3. AM
  4. AUX
- S<sub>2a</sub>, S<sub>2b</sub> SPEAKER 1.OFF 2.A 3.B 4.A+B  
 S<sub>3a</sub>, S<sub>3b</sub> TAPE MONITOR (1) 1.OFF 2.ON  
 S<sub>4a</sub>, S<sub>4b</sub> TAPE MONITOR (2) 1.STEREO 2.MONO  
 S<sub>5</sub> MODE 1.STEREO 2.MONO  
 S<sub>6a</sub>, S<sub>6b</sub> LOUDNESS 1.ON 2.OFF  
 S<sub>7</sub> HIGH FILTER 1.OFF 2.ON  
 S<sub>8</sub> ANTENNA 1.DISTANCE 2.LOCAL  
 S<sub>9</sub> MUTING 1.OFF 2.ON

- CAPACITOR
- OIL
  - MYLAR
  - ⊙ TANTALUM
  - ⊙ STYROL
  - △ CERAMIC
  - MICA
- ⊗ ALL RESISTORS 1/4WATT UNLESS OTHERWISE NOTED  
 ⊗ VOLTAGE AND CURRENT CHECK AT CIRCUIT METER 1V/20kΩ  
 ⊗ (C) INDICATE ONLY THE STEREO TUNING

